


SIC H

Snap-In Clamp (Pat.)

Copyright © Fi.Mo.Tec. S.p.A.
www.fimoworld.com

IST. 077 - REV. 0 - 01/19

INSTALLATION INSTRUCTIONS



WARNINGS!


Installation of products must be performed by qualified, trained and experienced personnel. Installation personnel must be correctly and safely equipped. Mounting instructions and warnings must be read prior to installation. Warnings alert you to possible dangers about improper use of product. Failure to observe warnings may result in injury or death to you or others.



Fi.Mo.Tec. S.p.A.
is certificated ISO 9001
and RoHS DIRECTIVES
compliant.


All rights reserved.
Passing on and copying of
this document, use and com-
munication of its contents
not permitted without Fi.Mo.
Tec. S.p.A. prior consent.

1




Insert Sic Snap-In clamp on the cable.

2




Press Sic Snap-In into hole.

3








Assure the correct hooking of the tabs.

4



Add further Snap-In clamps (up to 3 pcs).

POSSIBLE COMBINATIONS



Snap-In clamp wings are provided of anti-rotation pins. Avoid SIC rotation around the cable.
Do not strip power cables to avoid electrical risk or damaging cables.
Do not use clamp for different purposes.



MANUFACTURER DISCLAIMS ANY LIABILITY AND RESPONSABILITY FOR IMPROPER USE.
INSTALL USING PROPER SECURITY DEVICES.