INSTALLATION BULLETIN Universal Barrel Cushions BCU-Series

TYPICAL APPLICATIONS

Hanger Installation

STEP 1 Install Cushion around cable applying pressure to the expansion/compression ring located underneath the part number to assure cushion wraps around cable properly.

STEP 2 Install Hanger around cushion, then snap into 3/4" hole to secure the cable, cushion, and hanger





Cushion is designed to have a gap at the base to accommodate large diameter cables



Cable Block Installation

STEP1 Install Cushion around cable applying pressure to the expansion/compression ring located underneath the part number to assure cushion wraps around cable properly.



STEP 2

Place cushion and cable inside of cable block half with care to assure cushion is all the way inside of cable block. Place other half of cable block over cushion and tighten into position.





SPECIFICATIONS

PRODUCT DESCRIPTION

Universal Barrel Cushions provide an effective means for securing hybrid power and fiber cables throughout wireless applications. This versatile design ensures long-term integrity in extreme temperatures and UV applications for the life of your system.

NOTICE

Installation of this product should only be performed by trained, qualified and experienced personnel. Installation instructions for this product should be read throughly before installation is performed. The manufacturer and supplier of this product disclaims any liability or responsibility for the results of improper or unsafe installation practice.

MATERIAL LIST

Kit of 10 Universal Cushions

MOUNTING HARDWARE FOR PROPER INSTALLATION

- *Snap-in Hangers
- *Snap Stack Hangers
- *Butterfly Hangers
- *Clip Hangers
- *Half Clamp Cable Blocks
- *2-Hole Cable Blocks
 - * Ordered Separately





Visit us at: www.fimoworld.com - E-mail us at: customersupportUSA@fimoworld.com - "Building Sustainable Innovation"

Call us at U.S. Telephone: 1 (203) 759-3744