


HANGER KIT



POSITION	FIGURE	DESCRIPTION
1 FAU 50/150		Universal hose clamp
2 BAC 8		Socle with bow
3 BFI 8x400		Threaded bar
4 DAI 8		M8 hexagonal nut
5 REI 8		Elastic washer
6 GO		Round collar
7 GRR		Round cushion

MOUNTING INSTRUCTIONS

Mount on the pole the socle with bow **BAC 8** 2, by the universal hose clam **FAU 50/150** 1. Insert upon the socle the threaded bar **BFI 8x400** 3 in its suitable "V" shape seat, and tighten the screw.

Attach the other threaded bar end **BFI 8x400** 3 to the round collar **GO** 6 blocking it by the suitable nuts **DAI 8** 4 and the elastic washer **REI 8** 5.

Insert the flexible waveguide in the round cushion **GRR** 7 and in the round collar **GO** 6. Tighten the round collar side screws **GO** 6.

ST 010 - 3/11 - A6 - REV.0



All rights reserved.

Passing on and copying of this document, use and communication of its contents not permitted without Fi.Mo.Tec. S.p.A. prior consent.

