


HANGER KIT



POSITION	FIGURE	DESCRIPTION
1 FAU 50/150		Universal hose clamp
2 BAC 8		Socle with bow
3 BFI 8x400		Threaded bar
4 DAI 8		M8 hexagonal nut
5 REI 8		Elastic washer
6 GO		Round collar
7 GRR		Round cushion

MOUNTING INSTRUCTIONS

Mount on the pole the socle with bow **BAC 8** (2), by the universal hose clam **FAU 50/150** (1). Insert upon the socle the threaded bar **BFI 8x400** (3) in its suitable "V" shape seat, and tighten the screw.

Attach the other threaded bar end **BFI 8x400** (3) to the round collar **GO** (6) blocking it by the suitable nuts **DAI 8** (4) and the elastic washer **REI 8** (5).

Insert the flexible waveguide in the round cushion **GRR** (7) and in the round collar **GO** (6). Tighten the round collar side screws **GO** (6).

ST 010 - 3/11 - A6 - REV.0



All rights reserved.

Passing on and copying of this document,
use and communication of its contents not
permitted without Fi.Mo.Tec. S.p.A. prior consent.

